

Assembly instructions for sled with two and three trestles.

1. Contents of the set

- 4 U-shaped brackets for mounting under the seat
- 4 rectangular axle legs for mounting on the skids
- 4 plug-in wheels with metal axles
- 8 small and 8 larger wood screws

2. Position of the brackets

Mounting of the bracket on the second rung from the outside. The U-shaped brackets must be mounted offset to save space. For smaller sleds with only two trestles, the mounting must be adapted to the space conditions.

Trestle rear 1.5 cm distance between the trestle and the axle stub at the rear (the wheels can run either inside or outside)

7.5 cm distance between the trestle and the front steering knuckle (the wheels can run either on the inside or the outside)

3. Please place the sled in the direction of travel on the left side in front of you

The mounting on the runners is independent of model and size, the mounting under the seat has to be adapted to the space conditions on smaller sleds. If necessary, the wheels can be mounted inside instead of outside. Simply pull the bushings out of the steering knuckles and insert them through the steering knuckles from the inside to the outside.

4. Attaching the steering knuckles to the tops of the runners

The Roll-Rodel steering knuckles are suitable for all common wooden skids. Please mount the steering knuckles around so that the wheels are as vertical as possible. To do this, select the appropriate steering knuckle inclination depending on the inclination of the top of the skid. Place one steering knuckle each at the desired position 1.5 cm in front of the rear trestle and 7.5 cm in front of the front trestle and mark the two holes on the top side of the skid. Drill two holes (diameter 2 mm) 2.0 cm deep for each steering knuckle. Please do not interchange the position of the steering knuckles. Screw the steering knuckles to the skids with the larger screws. 5.

5. fastening the brackets under the seat surface

Two through holes (diameter 2-3 mm) must be drilled through the second rung of the seat surface for each holder. The distance between the holder and the nearest trestle must be 3.5 cm. The bracket is pre-drilled at the factory. Please press the bracket from above onto the rung in order to make markings with the small screws. Countersink the hole on the seat surface with a countersink or an 8 mm drill bit to prevent the screws from protruding. Now screw the small screws through the rung into the holder from above. **IMPORTANT:** Please use a screwdriver to screw in both screws three to four turns before using the cordless screwdriver to prevent injuries caused by rotation of the bracket. Please sand joining surfaces and glue with waterproof wood glue.

6. Use

The plug-in wheels can now be inserted into the axle legs on the skid or the U-shaped holders under the seat as required, whereby the axle always remains on the wheel. To insert, insert the axle into the plastic bushing as far as it will go while firmly pushing the metal bracket through. To lock, release the bracket and gently pull the wheel back out until it locks into place.

Important Notes:

Our Roll-Rodel will provide you with many years of safe, risk-free family fun, provided it is used in accordance with its intended purpose and the safety instructions below.

- The Roll-Rodel may not be used by children without a parent or guardian, as it can only be steered and braked to a limited extent (personal responsibility!).
- A maximum of 2 children (80 kg in total) may sit on the Roll-Rodel as long as the wheels are used.
- The pull belt may only be pulled/used by adult guardians, not by children! Do not pull the belt jerkily, so that the child does not fall off the Roll-Rodel.
- The backrest must be mounted so that the child's center of gravity is in front of the rear axles.
- Children may only be pulled on the Roll-Rodel on level paths with little traffic. The Roll sled may not be used on public roads. On slopes, the sled may only be used without wheels under the supervision of a parent or guardian.
- The sled is not designed for competitive sports or other competitive purposes. It may only be used for slow "strolling" with wheels and for sledging fun on snow. Do not jump off jumps, go through ice chutes or ride on toboggan runs.
- No structural modifications may be made to the sled.
- The sled, with or without wheels, must not be pulled by other vehicles.
- The sled should not be used after damage has been detected.
- When tobogganing, do not place your legs in the toboggan, but support them facing forward on both runners to be able to steer and brake. When tobogganing, you should hold on to the outer seat rails. Do not toboggan lying down with your head in front!
- Clothing must fit snugly and tightly. Avoid tobogganing with hanging, blowing scarves, there is a risk of strangulation!
- It is recommended to wear appropriate protective equipment (helmet, protectors, gloves).
- If you do not follow these instructions, the safety of your child may be compromised.